

## PARTS & INSTALLATION INSTRUCTIONS

### E-46 & E-47 ELECTRO-LIFT®

#### PARTS LIST

ITEM	STANDARD-UP THROUGH C-9		QTY.	DESCRIPTION	ITEM	STANDARD-UP THROUGH C-9		QTY.	DESCRIPTION
	1-1/8" x 6" Stroke E-46	1-1/8" x 8" Stroke E-47				1-1/8" x 6" Stroke E-46	1-1/8" x 8" Stroke E-47		
1	15153	15153	1	PUMP & MOTOR ASSY.	46	22293	22293	1	• Coupler, Male Half
	15054	15054	1	• Motor - 12 Volt	47	15606	15606	1	• Kit-Crossover Valve
2	15026	15026	1	• Pump Assy.	48			1	•• O-ring
3	15581	15581	1	•• Shaft Seal	49			1	•• O-ring
4	15045	15204	1	Cylinder Tank	50			1	•• Cage
5*	15131	15131	1	O-Ring 3-1/2 I.D.	51			1	•• O-ring w/Glyd. Ring
6*	15163	15163	1	O-Ring 1-15/16 I.D.	52			1	•• Poppet
7*	15198	15198	1	O-Ring 1-1/8 I.D.	53			1	•• Washer
8	15194	15194	1	Cover & Seal Assy.	54			1	•• Guide
9	05119	05119	1	• Wiper	55			1	•• Spring
10*	15131	15131	1	• O-Ring 3-1/2 I.D.	56			1	•• Spacer
11	15199	15199	1	• Sleeve	57			1	•• Disc
	08473	08473	1	PRESSURE RELIEF VALVE KIT	58			1	•• Plug
12	21805	21805	1	• Reducer Bushing 1/4 - 1/8	59			1	•• Adj. Screw
13	21806	21806	1	• Pressure Relief Valve	60			1	•• O-ring
14	15207	15205	1	Cylinder	61			1	•• Acorn Nut 9/16-18
15	15209	15209	1	Washer	*	15610	15610	1	•• Seal Kit-Crossover Valve (includes items 48, 49, 51, 60)
	15335	15761	1	RAM ASSEMBLY	62	15639	15639	1	•• Kit-Pilot Check Valve
16	15208	15206	1	• Ram	63			1	•• Ball, Steel
17	15158	15158	1	• Piston	64			1	•• Spring
18	15219	15219	1	• Piston Follower	65			1	•• Plug
19		15760	1	• Spacer	66	15609	15609	1	•• Piston
20*	15162	15162	1	• Packing Cup	67	15359	15359	1	•• Plug Valve Block
21*	15125	15125	1	• O-Ring 7/16 I.D.	68*	15126	15126	1	•• O-ring 9/16 I.D.
22			1	• Locknut 1/2-13	69	15697	15697	1	•• "B" Solenoid Assembly
23			3	Locknut 5/16-24	70	15382	15382	1	•• "B" Coil, Red Wire
24	15573	15573	1	Base & Strainer Assy.	71	15698	15698	1	•• "B" Cartridge Valve
25	15326	15326	1	• Strainer	*	15432	15432	1	•• Seal Kit-"B" Cartridge
26	15042	15203	3	Stud	72	15358	15358	1	•• "C" Solenoid Assembly
27	15043	15043	3	Stud	73	15430	15430	1	•• "C" Coil, Green Wire
28	15574	15574	1	PUMP CHECK VALVE KIT	74	15381	15381	1	•• "C"-Cartridge Valve
29*			1	• O-Ring 3/8 I.D.	*	15433	15433	1	•• Seal Kit-"C" Cartridge
30			1	• Seat	75	15576	15576	1	•• Kit-"B" Solenoid Check Valve
31			1	• Ball, 9/32	76			1	•• Ball, 7/16
32			1	• Spring	77			1	•• Spring
33*	15122	15122	3	O-Ring 1/4 I.D.	78	21826	21826	4	Scr., Soc. Head 5/16-18 x 1-1/2"
34	15620	15620	1	FILTER KIT - 1/2"	79	15646	15646	1	End Plate
35	15619	15619	1	• Filter	80	21859	21859	4	Scr., Soc. Head 5/16-18 x 3/4
36	21827	21827	1	• Plug w/O-Ring - 1/2"	81	15621	15621	1	Baffle
36	21827	21827	2	Plug w/O-Ring - 1/2"	82	21980	21980	2	Retainer Ring
34	15641	15641	1	FILTER KIT - 9/16"		15556	15556	1	VALVE ASSEMBLY
35	15619	15619	1	• Filter	83	15578	15578	1	•• Kit - Crossover Valve
36	21999	21999	1	• Plug w/O-Ring - 9/16"	84			1	•• Poppet
36	21999	21999	2	Plug w/O-Ring - 9/16"	85			1	•• Spring
34	15620	15620	2	FILTER KIT - 1/2"	86			1	•• O-Ring 1/4 I.D.
35	15619	15619	1	• Filter	87			1	•• Plug
36	21827	21827	1	• Plug w/O-Ring - 1/2"	88	15577	15577	1	•• Kit - "C" Solenoid Check Valve
36	21827	21827	1	Plug w/O-Ring - 1/2"	89			1	•• Ball 3/16
34	15641	15641	2	FILTER KIT - 9/16"	90			1	•• Spring
35	15619	15619	1	• Filter	91			1	•• Plug
36	21999	21999	1	• Plug w/O-Ring - 9/16"	92	15575	15575	1	•• Kit - Pilot Check Valve
36	21999	21999	1	Plug w/O-Ring - 9/16"	93			1	•• Ball
37*	15127	15127	1	O-Ring 5/8 I.D.	94			1	•• Spring
38*	21929	21929	3	Washer, Nylite 5/16	95			1	•• Plug
39	20697	20697	3	Locknut 5/16 - 24	96	15366	15366	1	•• Piston
40	15356	15356	1	"A" Solenoid Assembly	97			4	Scr., Soc. Head
41	15392	15392	1	• "A" Coil, Black Wire	98	15611	15611	1	Kit - Pump Relief Valve
42	15393	15393	1	• "A" Cartridge Valve	99			1	•• Poppet
*	15431	15431	1	•• Seal Kit, "A" Valve	100			1	•• Spring
40a	15661	15661	1	"A" Solenoid Assembly	101			1	•• Guide
41a	15659	15659	1	• "A" Coil, Black Wire	102			1	•• O-Ring
42a	15660	15660	1	• "A" Cartridge Valve	103			1	•• Retainer
*	15431	15431	1	•• Seal Kit, "A" Valve	104			1	•• Set Screw
43	15758	15758	1	• VALVE ASSY. w/COUP.	105			2	•• Washer w/O-Ring
44	22295	22295	1	•• Forged 90 Degree Elbow	106			1	•• Jam Nut
45	22294	22294	1	•• Coupler, Female Half	107			1	•• Acorn Nut

Parts indented are included in assembly under which they are indented.

- NOTES:**
- \*Parts included in Master Seal Kit Part No. 15456.
  - Set Crossover Relief Valve @ 3800 ± 400 P.S.I. @ 2-1/2 G.P.M. flow.
  - Set Pump Relief Valve @ 1650 ± 50 P.S.I. full flow.



Meyer Products and Diamond Equipment reserves the right, under its continuing product improvement program, to change construction or design details, specifications and prices without notice or without incurring any obligation.

Meyer Products  
18513 Euclid Ave. • Cleveland, Ohio 44112-1084  
Phone 486-1313 (Area Code 216)  
www.warranty@meyerproducts.com



Diamond Equipment  
6 Angell Lane • Damariscotta, ME 04543-9720  
Phone 563-2227 (Area Code 207)  
www.diamondplow.com • email info@diamondplow.com

# E-46, E-46H, E-47 and E-47H Exploded View



Note: Oil seepage, if any, at O-ring (60) is normal. DO NOT attempt to stop this seepage by further tightening of the Acorn Nut.

## GENERAL INFORMATION

Before the Meyer Electro-Lift® unit is disassembled for repairs, make certain that all the maintenance procedures have been checked; refer to Owner's Manual.

When the unit is to be overhauled, Master Seal Kit Part No. 15456 is required. This Kit contains all necessary Seals for rebuilding. **NOTE: DO NOT REUSE OLD O-RINGS.**

When ordering parts, furnish Type of Unit, Part No., Name and Description.

**These instructions are intended as a guideline for overhaul of an E-46/E-47 Electro-Lift® unit.**

**More detailed information covering principles of Operation, Troubleshooting, Disassembly and Repair are found in Electro-Lift® Service Manual 1-562. This is available for a nominal fee from your Meyer Distributor or directly from Meyer Products.**

## DISASSEMBLY AND INSPECTION OF UNIT

Drain fluid from the unit by removing Pressure Relief Valve (13) or Drain Plug (36). Clamp Sump Base (24) firmly into vise.

1. To disassemble COVER ASSEMBLY, TANK, RAM & CYLINDER PARTS, remove three Locknuts (39).
2. To disassemble MOTOR from PUMP, loosen Motor mounting bolts, but DO NOT REMOVE.

**Note:** Motor end plate to be held in place. Temporarily install two 1/4-20 nuts on the motor mounting bolts to keep motor intact. Remove nuts when reinstalling Motor to pump.

3. To disassemble Pump from Base, remove three Locknuts (23).
4. To disassemble VALVE BLOCK from BASE, remove Soc. Hd. Screws (78, 80 or 97).

## SUBASSEMBLIES - INSPECTION

### 1. COVER ASSEMBLY, TANK, RAM & CYLINDER PARTS:

- a) Check Cover (8), and Base (24) castings for cracks and damage.
- b) Replace Wiper Seal (9) pressed in Cover (8).
- c) Inspect Sleeve (11), Piston (17), the Piston Follower (18), Spacer (19) for excessive wear. Replace Packing Cup (20). Inspect Cylinder (14) for scoring and pitting in bore.
- d) Inspect Ram (16) for nicks and rust.

### 2. MOTOR (1)

**Note:** Complete Motor Assemblies are only available from Meyer Products. Service and repair parts can be purchased from your nearest authorized Prestolite or American Bosch Service Stations.

- a) Prestolite Motor can be identified by a "Domed Top Cover" and name "Prestolite" stamped on Motor Body.
- b) American Bosch Motors have a "Flat Top Cover" and no identifying marks.

### 3. PUMP (2)

**DO NOT at any time disassemble this Pump. This will void the warranty.**

- a) The damaged pump drive Shaft Seal (3) may be removed by careful extraction with a pointed tool. Dip new Seal in oil and with lip down, press into Pump Housing flush to 1/32 inch below face of boss.

### 4. BASE (24)

- a) Remove and clean Solenoid (40) and inspect for external damage.
- b) Test Coil (41) for electrical continuity. Nominal Coil resistance is 9.6 ohms. Replace O-rings from Seal Kit Part No. 15431 contained in Seal Kit No. 15456.
- c) To reassemble, carefully guide the Coil (41) over the Valve Cartridge (42) and use the original External Brass Nut.
- d) Remove and clean the Filter Screen (34) using kerosene and blow out with air. Replace O-rings (33) from Seal Kit No. 15456.

### 5. VALVE BLOCKS

- a) Remove items (69), (76) & (77). Clean "B" Solenoid (69) and inspect for damage. Disassemble Cartridge Valve (71) and replace O-rings from Seal Kit No. 15432 contained in Seal Kit No. 15456.
- b) Remove and clean "C" Solenoid (72) and inspect for damage. Disassemble Cartridge Valve (74) and replace O-rings and nylon back-up rings from Seal Kit No. 15433 contained in Seal Kit No. 15456. Be certain O-rings and spacers are oriented properly.
- c) Test both Coils (70 & 73) for electrical continuity. Nominal Coil resistance is 3.7 ohms.
- d) Remove Plug (67) and Piston Assembly (66 or 96) and inspect the Piston for scratches. Replace O-ring (68) from Seal Kit No. 15456.
- e) Remove Pilot Check Valve Parts (62 or 92) and inspect all parts for damage.
- f) Remove Plugs (87) with caution as these are spring loaded.
- g) Remove all parts of Item 47 or 83 and inspect for damage. Replace O-rings from Seal Kit No. 15456. Set adjustable crossover to 3800 P.S.I. ± 400 P.S.I.
- h) Remove all parts of Item 88 and inspect for damage.
- i) With parts removed from Valve Block, clean and blow out with air to remove any foreign particles in Block.

### 6. UNIT REASSEMBLY

- a) Before reassembling, make certain all components and sub-assemblies are clean and free from all dirt and other foreign material.
- b) When replacing parts, install (63), (64) & (65) or (93), (94) & (95) before installing Piston (66 or 96) and Plug (67).
- c) Motor mounting bolts must be sealed with Permatex or an all weather Type sealant.
- d) **USE NEW SEALS AND M-1 FLUID WHEN REASSEMBLING THE UNIT.**
- d) Proper fluid level is 1-1/2" below filler hole. It must be checked with Lift Ram fully retracted.